

SHOP MANUAL

DUMP TRUCK

SERIAL NUMBERS:

930E-5SE A50008 & UP

930E-5SE

This material is proprietary to Komatsu and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

00 CONTENTS AND FOREWORD

Contents

00 CONTENTS AND FOREWORD.....	00-1
Foreword.....	00-17
How to Read the Shop Manual.....	00-17
Safety Alert Symbol and Signal Words.....	00-18
General Precautions Common to Operation and Maintenance.....	00-19
Preparations for Safe Operation.....	00-19
Fire and Explosion Prevention.....	00-21
Precautions When Getting On or Off the Machine.....	00-24
Precautions for Cab and Working Around Machine.....	00-26
Precautions for Diesel Exhaust Fluid (DEF).....	00-27
Operation Precautions.....	00-30
Precautions at Jobsite.....	00-30
Precautions in Starting Engine.....	00-31
Precautions During Operation.....	00-33
Maintenance Precautions.....	00-36
Precautions Before Inspection and Maintenance.....	00-36
Precautions During Inspection and Maintenance.....	00-41
Precautions for Electrical Equipment.....	00-49
Primary Causes of Wiring Harness Failure.....	00-49
Control Cabinet Capacitor Discharge.....	00-52
Hydraulic Equipment Precautions.....	00-53
01 SPECIFICATIONS.....	01-1
Specifications.....	01-2
Specifications: 930E-5SE.....	01-2
Recommended Fuel, Coolant, and Lubricant.....	01-3
Suspension Cylinder Oil and Nitrogen Specifications.....	01-4
Wheel Motor Oil Specifications.....	01-5
10 STRUCTURE AND FUNCTION.....	10-1
Steering System.....	10-2
Steering System Layout.....	10-2
Steering System Operation.....	10-2
Steering Bleeddown Manifold.....	10-4
Steering Control Unit.....	10-5
Steering Accumulators (Piston Type).....	10-6
Steering/Brake Pump Operation.....	10-6
Flow Amplifier Operation.....	10-8
Hoist System.....	10-16
Hoist System Layout.....	10-16
Hoist System Operation.....	10-17
Hoist Control Valve.....	10-18
Hoist Pilot Valve.....	10-20
Brake System.....	10-21
Service Brake System Layout.....	10-21
Hydraulic Brake Cabinet Layout.....	10-22
Service Brake Operation.....	10-22
Parking Brake Operation.....	10-23
Brake Lock Operation.....	10-23
Secondary Braking and Auto Apply.....	10-24

Electrical System, 24V.....	10-25
Battery Power Supply.....	10-25
Battery Disconnect Switches.....	10-26
Engine Starting System.....	10-27
Auxiliary Control Cabinet Components.....	10-28
Body-Up Switch.....	10-28
Hoist Limit Switch.....	10-29
Automatic Lubrication (Auto Lube) System.....	10-30
Automatic Lubrication (Auto Lube) Grease Pump and Reservoir.....	10-30
Automatic Lubrication (Auto Lube) System Operation.....	10-31
Suspensions.....	10-33
Engine Emissions After-Treatment System Operations.....	10-34
 20 STANDARD VALUE TABLE.....	 20-1
Standard Value Table.....	20-2
 30 TEST AND ADJUST.....	 30-1
Hydraulic Systems.....	30-2
Hydraulic System Checkout Procedures.....	30-2
Hydraulic System Checkout Sheet.....	30-13
Steering System Leakage Check.....	30-16
Toe-In Adjustment.....	30-17
Hoist Cylinder Leakage Test.....	30-18
Steering Cylinder Leakage Test.....	30-19
Checking the Steering/Brake Pump Control Pressures.....	30-19
Adjusting the Steering/Brake Pump Control Pressures.....	30-20
High Altitude Steering/Brake Pump Adjustment.....	30-22
Brake System.....	30-23
Brake System Leakage Check.....	30-23
Brake Piston Leakage Test.....	30-24
Parking Brake Piston Leakage Test.....	30-24
Brake Floating Seal Pressure Test.....	30-24
Oil Separation Seal Pressure Test (Air Pressure Method).....	30-25
Oil Separation Seal Pressure Test (Oil Pressure Method).....	30-25
Wet Disc Brake Bleeding Procedure.....	30-26
Parking Brake Bleeding Procedure.....	30-26
Wet Disc Brake Wear Inspection.....	30-27
Parking Brake Wear Inspection.....	30-28
Accumulators and Suspensions.....	30-29
Bladder Accumulator Charging Procedure.....	30-29
Bladder Accumulator Leakage Test.....	30-30
Bladder Accumulator Storage.....	30-31
Piston Accumulator Charging Procedure.....	30-32
Piston Accumulator Leakage Test.....	30-33
Piston Accumulator Storage.....	30-34
Check for Improper Suspension Charge.....	30-35
Suspension Oiling and Charging Procedures.....	30-36
Oiling and Charging Tools and Support Blocks.....	30-37
Nitrogen Charging Kit Installation.....	30-41
Nitrogen Charging Kit Removal.....	30-41
Front Suspension Oiling and Charging.....	30-42
Rear Suspension Oiling and Charging.....	30-45
Suspension Pressure Test.....	30-48
Automatic Lubrication (Auto Lube) System.....	30-49

Prime the Auto Lube Pump.....	30-49
Prime the Auto Lube Grease Lines.....	30-49
Auto Lube System Checkout.....	30-50
Adjust the Auto Lube Cycle Timing.....	30-51
Cab Air Conditioning.....	30-53
Refrigerant Leak Detection.....	30-54
A/C System Performance Test.....	30-54
Check the A/C System Oil.....	30-55
A/C System Flushing Procedure.....	30-56
Manifold Gauge Set Installation.....	30-57
Refrigerant: Recycled vs Reclaimed.....	30-58
Refrigerant Recovery Procedure.....	30-58
Evacuate the A/C System.....	30-58
Charge the A/C System.....	30-59
Electrical Systems.....	30-61
Shutdown Procedure for Drive System Service.....	30-61
Electrical System Checkout Procedures.....	30-62
Visual Checks.....	30-62
Resistance Checks.....	30-62
Voltage Checks.....	30-62
Truck Function Checks.....	30-65
Interface Module (IM) Checks.....	30-66
KOMTRAX Plus II Checks.....	30-66
Payload Meter (PLM) Checks.....	30-66
Drive System Checks.....	30-66
Engine Delayed Shutdown Smart Timer Check.....	30-67
Hoist Limit Switch Check.....	30-68
Electrical System Checkout Sheet.....	30-68
Interface Module 2 (IM2).....	30-70
Interface Module 2 Software and Tools.....	30-70
Program the IM2 Controller.....	30-70
Interface Module 2 Checkout Procedures.....	30-72
Check for IM Fault Codes.....	30-72
Checking Digital Inputs to the IM2.....	30-73
Checking Analog Inputs to the IM2.....	30-74
Checking Serial Communication to the IM.....	30-75
Checking Outputs from the IM2.....	30-75
Interface Module 2 Checkout Sheet.....	30-76
Payload Meter IV.....	30-79
Payload Meter IV Software and Tools.....	30-79
Payload Meter IV System Configuration.....	30-79
Configuring a Static IP Address.....	30-79
Payload Meter IV Software Installation.....	30-82
Payload Meter IV Data Downloading.....	30-82
Payload Meter IV Checkout Procedure.....	30-83
Payload Meter IV Checkout Sheet.....	30-89
KOMTRAX Plus II.....	30-90
KOMTRAX Plus II Software and Tools.....	30-90
Komtrax Plus II Controller Ethernet Connection.....	30-90
KOMTRAX Plus II Configuration.....	30-91
GPS Connection Test.....	30-94
Satellite Connection Test.....	30-96
Komtrax Plus II System Initialization.....	30-99
KomVision.....	30-101
KomVision Setup and Calibration Requirements.....	30-101
KomVision Initial Setup and Checkout Procedure.....	30-101

This is the sample of the manual

**Click on the download link for
complete manual**

Download Link

KomVision Checkout Sheet.....	30-107
KomVision Calibration Sheets.....	30-109
Calibration Sheet Layout.....	30-109
Unfold and Fold Calibration Sheet.....	30-112
Calibration Sheet Placement.....	30-114
KomVision Camera Calibration Procedures.....	30-115
Automatic 6 Camera Calibration.....	30-115
Manual 6 Camera Calibration.....	30-118
1 Camera Calibration.....	30-120
KomVision Radar Setting Procedure.....	30-123
Komatsu Wireless Bridge (KWB).....	30-126
Komatsu Wireless Bridge Software and Tools.....	30-126
Bullet Wireless Radio Configuration.....	30-126
Bullet Wireless Radio Installation.....	30-129
NanoStation Access Point Configuration.....	30-130
NanoStation Access Point Connection Test.....	30-132
Tire Monitoring System.....	30-134
Tire Monitoring System Software and Tools.....	30-134
Tire Monitoring System Software Installation.....	30-134
Tire Monitoring System Configuration.....	30-134
Connecting to the Tire Monitoring System Web Server.....	30-134
Configuring a Static IP Address.....	30-135
Tire Monitoring System Reset.....	30-137
Tire Monitoring System Checkout Procedure.....	30-137
Tire Monitoring System Checkout Sheet.....	30-139

40 TROUBLESHOOTING..... 40-1

Fuses, Diodes and Relays.....	40-2
Standard Truck Fault Codes.....	40-13
A001.....	40-13
A002.....	40-13
A003.....	40-14
A004.....	40-14
A005.....	40-15
A006.....	40-15
A007.....	40-16
A008.....	40-16
A011.....	40-17
A013.....	40-17
A014.....	40-18
A016.....	40-18
A017.....	40-18
A018.....	40-19
A019.....	40-19
A022.....	40-20
A101.....	40-20
A103.....	40-21
A104.....	40-22
A105.....	40-22
A109.....	40-23
A111.....	40-23
A115.....	40-24
A117.....	40-25
A118.....	40-25
A123.....	40-26

A124.....	40-27
A125.....	40-27
A126.....	40-28
A127.....	40-29
A128.....	40-29
A139.....	40-30
A145.....	40-30
A146.....	40-31
A152.....	40-32
A153.....	40-32
A154.....	40-33
A155.....	40-34
A158.....	40-35
A166.....	40-35
A167.....	40-36
A168.....	40-37
A169.....	40-37
A170.....	40-38
A171.....	40-38
A172.....	40-39
A173.....	40-39
A184.....	40-40
A190.....	40-41
A193.....	40-41
A194.....	40-42
A195.....	40-42
A196.....	40-43
A197.....	40-44
A198.....	40-44
A199.....	40-45
A200.....	40-45
A201.....	40-46
A202.....	40-46
A203.....	40-47
A204.....	40-47
A205.....	40-48
A206.....	40-48
A207.....	40-49
A213.....	40-50
A214.....	40-51
A215.....	40-52
A216.....	40-53
A223.....	40-53
A230.....	40-54
A231.....	40-55
A233.....	40-56
A235.....	40-57
A236.....	40-58
A237.....	40-59
A240.....	40-59
A242.....	40-60
A243.....	40-61
A244.....	40-61
A245.....	40-62
A246.....	40-63
A247.....	40-63

A248.....	40-64
A249.....	40-64
A250.....	40-65
A251.....	40-66
A252.....	40-67
A253.....	40-68
A256.....	40-68
A257.....	40-69
A258.....	40-70
A260.....	40-70
A261.....	40-71
A262.....	40-72
A264.....	40-73
A265.....	40-74
A266.....	40-74
A267.....	40-75
A268.....	40-76
A270.....	40-76
A272.....	40-77
A273.....	40-79
A274.....	40-79
A275.....	40-80
A277.....	40-81
A278.....	40-82
A279.....	40-83
A280.....	40-83
A281.....	40-84
A282.....	40-85
A283.....	40-85
A284.....	40-87
A285.....	40-87
A286.....	40-88
A292.....	40-89
A303.....	40-90
A304.....	40-91
A305.....	40-92
A307.....	40-92
A309.....	40-93
A310.....	40-94
A311.....	40-95
A312.....	40-96
A313.....	40-97
A315.....	40-97
A316.....	40-98
A317.....	40-99
A318.....	40-101
A328.....	40-101
A332.....	40-102
A333.....	40-102
A334.....	40-103
A335.....	40-104
A337.....	40-104
A338.....	40-105
A339.....	40-105
A340.....	40-106
A341.....	40-106

A342.....	40-107
A343.....	40-108
A344.....	40-108
A345.....	40-109
A346.....	40-109
A347.....	40-110
A348.....	40-111
A349.....	40-111
A350.....	40-112
A351.....	40-112
A352.....	40-113
A353.....	40-114
A354.....	40-115
A355.....	40-115
A356.....	40-116
A357.....	40-116
A358.....	40-117
A359.....	40-118
A360.....	40-119
A361.....	40-120
A362.....	40-120
A363.....	40-121
A364.....	40-122
A365.....	40-122
A366.....	40-123
A400.....	40-123
A401.....	40-124
A402.....	40-125
A403.....	40-125
A404.....	40-126
A405.....	40-126
A406.....	40-126
A407.....	40-127
A408.....	40-127
A409.....	40-128
A410.....	40-129
A411.....	40-129
A412.....	40-130
A413.....	40-130
A414.....	40-130
A415.....	40-131
A416.....	40-131
A417.....	40-132
A418.....	40-133
A419.....	40-133
A420.....	40-134
A421.....	40-134
A422.....	40-134
A423.....	40-135
A424.....	40-135
A425.....	40-136
A426.....	40-137
A427.....	40-137
A428.....	40-138
A429.....	40-138
A430.....	40-138

A431.....	40-139
A432.....	40-139
A433.....	40-140
A434.....	40-141
A435.....	40-141
A436.....	40-142
A437.....	40-142
A438.....	40-142
A439.....	40-143
A440.....	40-143
A441.....	40-144
A442.....	40-145
A443.....	40-145
A444.....	40-146
A445.....	40-146
A446.....	40-146
A447.....	40-147
Aftertreatment System Fault Codes.....	40-148
CA256.....	40-148
CA1677.....	40-149
CA1678.....	40-151
CA1682.....	40-154
CA1683.....	40-162
CA1684.....	40-165
CA1685.....	40-166
CA1686.....	40-167
CA1695.....	40-168
CA1712.....	40-169
CA1713.....	40-170
CA1714.....	40-171
CA1715.....	40-172
CA1887.....	40-173
CA2771.....	40-173
CA3142.....	40-177
CA3143.....	40-178
CA3146.....	40-179
CA3147.....	40-180
CA3232.....	40-181
CA3497.....	40-184
CA3498.....	40-185
CA3547.....	40-186
CA3558.....	40-186
CA3559.....	40-188
CA3562.....	40-190
CA3563.....	40-191
CA3567.....	40-193
CA3571.....	40-195
CA3572.....	40-197
CA3573.....	40-200
CA3574.....	40-201
CA3575.....	40-202
CA3712.....	40-204
CA3713.....	40-205
CA3714.....	40-207
CA3867.....	40-208
CA3868.....	40-209

CA3878.....	40-212
CA3988.....	40-212
CA3995.....	40-216
CA4113.....	40-217
CA4114.....	40-218
CA4119.....	40-219
CA4121.....	40-219
CA4152.....	40-220
CA4164.....	40-223
CA4165.....	40-224
CA4166.....	40-227
CA4168.....	40-228
CA4169.....	40-230
CA4174.....	40-231
CA4175.....	40-233
CA4233.....	40-235
CA4234.....	40-236
CA4243.....	40-237
CA4277.....	40-238
CA4456.....	40-239
CA4457.....	40-247
CA4458.....	40-249
CA4459.....	40-251
CA4461.....	40-253
CA4462.....	40-254
CA4464.....	40-256
CA4465.....	40-259
CA4466.....	40-261
CA4467.....	40-269
CA4474.....	40-270
CA4475.....	40-272
CA4572.....	40-274
CA4677.....	40-279
CA4679.....	40-284
CA4682.....	40-285
CA4731.....	40-286
CA4732.....	40-286
CA4736.....	40-287
CA4737.....	40-288
CA4738.....	40-288
CA4739.....	40-289
CA4745.....	40-289
CA4768.....	40-290
CA4769.....	40-291
CA4842.....	40-292
CA4863.....	40-292
CA5115.....	40-293
CA5116.....	40-295
CA5117.....	40-298
CA5247.....	40-300
CA5653.....	40-301
CA5654.....	40-303
CA5725.....	40-304
CA5727.....	40-309
CA5728.....	40-312
CA5729.....	40-314

CA5748.....	40-315
CA5749.....	40-317
CA5751.....	40-319
CA5753.....	40-321
CA5755.....	40-324
CA5756.....	40-329
CA5758.....	40-331
CA5768.....	40-332
CA5769.....	40-334
CA5771.....	40-336
CA5772.....	40-338
CA5773.....	40-340
CA5774.....	40-343
CA5775.....	40-345
CA5776.....	40-351
CA5778.....	40-353
CA5779.....	40-354
CA5887.....	40-356
CA5888.....	40-357
CA5889.....	40-357
CA5891.....	40-358
CA5892.....	40-358
CA5893.....	40-359
CA6692.....	40-360
CA6693.....	40-360
CA6694.....	40-361
CA6695.....	40-362
CA6696.....	40-363
CA6697.....	40-364
CA6855.....	40-365
CA6856.....	40-367
KomVision Fault Codes.....	40-369
Troubleshoot the Steering System.....	40-380
Steering System Troubleshooting Guide.....	40-380
Basic Hydraulic System Checks.....	40-381
Steering/Brake Pump Troubleshooting Guide.....	40-382
Steering/Brake Pump Troubleshooting Checks.....	40-386
Steering/Brake Pump Fails to Unload.....	40-386
Steering/Brake Pump Fails to Develop Pressure.....	40-386
Steering/Brake Pump Slow to Develop Pressure.....	40-387
Steering/Brake Pump Control Valve Inspection.....	40-388
Steering/Brake Pump Case Drain Check.....	40-389
Troubleshoot the Auto Lube System.....	40-390
Troubleshoot the HVAC System.....	40-394
Control Panel Configurations.....	40-394
Diagnostics Mode.....	40-395
Error Codes.....	40-395
Advanced Diagnostics.....	40-395
Firmware Version.....	40-396
Additional HVAC Troubleshooting Chart.....	40-396
Voltage Levels.....	40-398
Troubleshoot the Electronic Fan Clutch.....	40-400

50 DISASSEMBLY AND ASSEMBLY.....50-1

Special Tools List.....	50-2
-------------------------	------

Wheels, Spindles and Rear Axle.....	50-4
General Precautions for Tires and Rims.....	50-4
Lubricants for Tire and Rim Service.....	50-4
Tire Inflation.....	50-5
Rim Components.....	50-5
Wheel Stud Maintenance.....	50-6
Rear Outer Wheel Stud Installation.....	50-7
Front Wheel Removal.....	50-8
Front Wheel Installation.....	50-10
Rear Wheel Removal.....	50-11
Rear Wheel Installation.....	50-14
Lock Ring Removal.....	50-16
Lock Ring Installation.....	50-18
Tire Removal (Front 5-Piece Rim).....	50-19
Tire Removal (Rear Outer 7-Piece Rim).....	50-23
Tire Removal (Rear Inner 5-Piece Rim).....	50-24
Tire and Rim Preparation.....	50-26
Tire Installation (Front 5-Piece Rim).....	50-27
Tire Installation (Rear Inner 5-Piece Rim).....	50-28
Tire Installation (Rear Outer 7-Piece Rim).....	50-29
Front Wheel Hub and Spindle Removal.....	50-30
Spindle Removal While Off the Truck.....	50-36
Front Wheel Hub and Spindle Installation.....	50-37
Spindle, Hub and Brake Assembly Cross-Section View.....	50-41
Front Wheel Hub and Spindle Disassembly.....	50-42
Front Wheel Hub and Spindle Cleaning and Inspection.....	50-50
Front Wheel Hub and Spindle Assembly.....	50-51
Hub Floating Seal Installation.....	50-62
Rear Axle Removal.....	50-66
Rear Axle Cleaning and Inspection.....	50-68
Rear Axle Installation.....	50-68
Anti-Sway Bar Removal.....	50-69
Anti-Sway Bar Installation.....	50-72
Pivot Pin Removal.....	50-74
Pivot Pin Installation.....	50-75
Pivot Eye Bearing Wear Inspection.....	50-77
Pivot Eye Bearing Replacement.....	50-78
Pivot Eye Removal.....	50-78
Pivot Eye Installation.....	50-79
Wheel Motor Removal.....	50-80
Wheel Motor Cleaning and Inspection.....	50-82
Wheel Motor Installation.....	50-83
Steering System.....	50-87
Steering Control Unit Removal.....	50-87
Steering Control Unit Installation.....	50-88
Steering Control Unit Disassembly.....	50-90
Steering Control Unit Assembly.....	50-92
Steering Column Removal.....	50-95
Steering Column Installation.....	50-97
Steering Wheel Removal.....	50-99
Steering Wheel Installation.....	50-99
Bleeddown Manifold Removal.....	50-100
Bleeddown Manifold Installation.....	50-101
Flow Amplifier Removal.....	50-102
Flow Amplifier Installation.....	50-103
Steering Pin Joint Wear Inspection.....	50-104

Tie Rod Removal.....	50-106
Tie Rod Installation.....	50-107
Steering Cylinder Removal.....	50-109
Steering Cylinder Installation.....	50-110
Steering Cylinder Disassembly.....	50-111
Steering Cylinder Cleaning and Inspection.....	50-113
Steering Cylinder Assembly.....	50-114
Steering/Brake Pump Removal.....	50-116
Steering/Brake Pump Installation.....	50-117
Piston Steering Accumulator Removal.....	50-119
Piston Steering Accumulator Installation.....	50-121
Piston Steering Accumulator Disassembly.....	50-123
Piston Accumulator Cleaning and Inspection.....	50-125
Piston Seal Replacement.....	50-125
Piston Steering Accumulator Assembly.....	50-126
Brake System.....	50-129
Brake Valve Removal.....	50-129
Brake Valve Installation.....	50-130
Brake Valve/Pedal Disassembly.....	50-132
Brake Valve/Pedal Assembly.....	50-133
Front Brake Dual Relay Valve Removal.....	50-136
Front Brake Dual Relay Valve Installation.....	50-137
Rear Brake Dual Relay Valve Removal.....	50-138
Rear Brake Dual Relay Valve Installation.....	50-139
Brake Manifold Removal.....	50-141
Brake Manifold Installation.....	50-141
Brake Manifold Component Replacement.....	50-142
Piston Brake Accumulator Removal.....	50-143
Piston Brake Accumulator Installation.....	50-144
Piston Brake Accumulator Disassembly.....	50-146
Piston Accumulator Cleaning and Inspection.....	50-148
Piston Seal Replacement.....	50-148
Piston Brake Accumulator Assembly.....	50-149
Front Wheel Brake Disassembly.....	50-151
Wheel Brake Cleaning and Inspection.....	50-154
Front Wheel Brake Assembly.....	50-154
Rear Wheel Brake Removal.....	50-158
Rear Wheel Brake Installation.....	50-159
Rear Wheel Brake Disassembly.....	50-161
Wheel Brake Cleaning and Inspection.....	50-165
Rear Wheel Brake Assembly.....	50-165
Brake Floating Seal Installation.....	50-170
Parking Brake Removal.....	50-175
Parking Brake Installation.....	50-177
Parking Brake Disassembly.....	50-178
Parking Brake Cleaning and Inspection.....	50-181
New Parking Brake Disc Cleaning and Inspection.....	50-182
Parking Brake Assembly.....	50-183
Hoist System.....	50-186
Hoist Pump Removal.....	50-186
Hoist Pump Installation.....	50-189
Hoist Pump Disassembly.....	50-193
Hoist Pump Inspection.....	50-198
Hoist Pump Assembly.....	50-198
Hoist Control Valve Removal.....	50-205
Hoist Control Valve Installation.....	50-206

Hoist Control Valve Service.....	50-208
Hoist Control Valve O-Ring Replacement.....	50-208
Inlet Section Disassembly.....	50-210
Inlet Section Assembly.....	50-211
Rear Spool Section Disassembly.....	50-213
Rear Spool Section Assembly.....	50-215
Front Spool Section Disassembly.....	50-216
Front Spool Section Assembly.....	50-218
Overcenter Manifold Service.....	50-219
Hoist Pilot Valve Removal.....	50-220
Hoist Pilot Valve Installation.....	50-221
Hoist Pilot Valve Disassembly.....	50-221
Hoist Pilot Valve Cleaning and Inspection.....	50-223
Hoist Pilot Valve Assembly.....	50-223
Hoist Cylinder Removal.....	50-226
Hoist Cylinder Installation.....	50-229
Hoist Cylinder Disassembly.....	50-232
Hoist Cylinder Cleaning and Inspection.....	50-241
Quill Installation.....	50-242
Quill Check Ball and Plug Installation.....	50-244
Hoist Cylinder Assembly.....	50-245
Suspensions.....	50-257
Front Suspension Removal.....	50-257
Front Suspension Cleaning and Inspection.....	50-258
Front Suspension Installation.....	50-259
Front Suspension Bolted Joint Inspection.....	50-264
Front Suspension Charging Valve Replacement.....	50-265
Front Suspension Disassembly.....	50-265
Front Suspension Assembly.....	50-270
Rear Suspension Removal.....	50-274
Rear Suspension Installation.....	50-277
Rear Suspension Charging Valve Replacement.....	50-281
Rear Suspension Disassembly.....	50-281
Rear Suspension Cleaning and Inspection.....	50-283
Rear Suspension Assembly.....	50-284
Dump Body and Structures.....	50-286
Dump Body Removal.....	50-286
Dump Body Inspection.....	50-287
Dump Body Installation.....	50-288
Body Pads Removal.....	50-289
Body Pads Installation.....	50-290
Body Pad Shimming Procedure.....	50-290
Diagonal Ladder Removal.....	50-291
Diagonal Ladder Installation.....	50-292
Grille and Hood Assembly Removal.....	50-294
Grille and Hood Assembly Installation.....	50-295
Egress Gate Adjustment.....	50-297
Retarding Grid Removal.....	50-298
Retarding Grid Installation.....	50-299
RH Deck Removal.....	50-300
RH Deck Installation.....	50-302
LH Deck Removal.....	50-304
LH Deck Installation.....	50-305
Control Cabinet Removal.....	50-307
Control Cabinet Installation.....	50-308
Auxiliary Control Cabinet Removal.....	50-310

This is the sample of the manual

**Click on the download link for
complete manual**

Download Link